

Using the touch pad on the wall, Click on the down arrow about 10 times.
On your PC, turn the volume down to halfway. (these 2 steps ensure you do not damage the speakers or other equipment)

Now, using the touch pad on the wall, click on Projector, then click on PC1 twice.
use the up arrow to turn it up slightly.
Clicking 2 times SHOULD make your sound work.